













JP511M1 PART LIST




序号 Item.	物料代码 Material code	图片 Picture	方向 Direction	名称 Name
1	2JP101.1-1			2JP101调节支撑板(M4) M4 adjustable support Length: 14mm width:12mm
2	SJPX1.1-2			调节块下张紧块 Tension block for bottom block length:32mm
3	2JP101.1-7			调节块下 Bottom block
4	SJPX2.1-1			调节块上张紧块长 Tension block for upper block length:40mm For upper block(front)
5	2JP101.1-8			调节块上 Upper block
6	2JP101.1-6			2JP101调节块(M4) 2JP101 Block(M4)
7	2JP101.1-9			调节块上(正面) Upper block(front)
8	2JP101.1-5			调节螺丝长(M4) Adjustiong screw long(M4)

9	2JP101.1-4			调节螺丝(M4) Adjusting screw (M4)
10	SJPX012-3			31连杆 31 Rod (45mm total length)
11	SJPX1.5-1		L/R	侧面叠片高速垫条 Side high speed stripe
12	SJPX1.3-10		L/R	侧面垫条(普通机) Side normal speed stripe
13	JP507M-16		L/R	JP507M动刀 (钨钢) JP507M cutter
14	JPX1.4-3		L/R	前拨叉 Front fork (yellow)
15	SJPX1.3-7			气缸传动支撑 Cylinder support
16	SJPX1.3-9			挡圈 Ring
17	SJPX1.4-21			拨叉挡块 Fork stop

18	SJPX1.4-27			挡块固定螺母 Square nut
19	SJPX1.4-29B			进给轮轴（加长） Shaft (long)
20	SJPX1.4-30		L/R	前摆杆 Swing level
21	SJPX1.4-33			拨叉隔圈 Fork spacer
22	SJPX1.4-32			拨叉连接销 Fork pin
23	2JP110M-7		L/R	2JP110M前拨叉复位簧 2JP110M Fork return spring
24	JPX4.4-20			动刀复位簧(加强) Return spring for cutter
25	SX-41			张紧弹簧 Tension spring
26	SX-41			固定杆扭簧 Torsional spring

27	SJPX301-11			拨叉摆杆挡圈 Fokr rod ring
28	2JP302M.1-14			2JP302摆杆复位簧 Shift return spring
29	JP506B-2			JP506B 定刀 JP506B Bottom knife
30	JP506B-4			JP506B拨叉摆杆 JP506B Swing level
31	JP506B-7			JP506B导片板 (2-9/3-5/4-7) Sequin guide
32	JP506B-14			JP506B定位板 JP506 fixed pin
33	JP506B-20			JP506B定位板扭簧 506B return spring
34	2J1Z06-08			动刀复位座 Movable block
35	2JP302M.1-11			2JP302M连杆A 2JP302M rod A

36				Motor:42HS051DF200A-18
37				气缸: 16x60 Cylinder 16x60
38				调节阀 Valve
39				杆端关节轴承 SI3P/K Rod end bearing
40				双头螺柱M3X40 Screwed rod:M3X40