


CHAMPION DEVICE PARTS CATALOGUE




Taping device PDX12A




PDX12A TAPPING DEVICE PDX12A-1

序号 Item No.	名称 Description	序号 Item No.	名称 Description
PDX12A-1-1	大盘带机壳(PDX5-9 补充加工) Tapping device body	PDX12A-1-21	标准型弹性垫圈Φ5 Spring waher:Φ5
PDX12A-1-2	轴承: MF148ZZ Bearing:MF148ZZ	PDX12A-1-22	六角螺母:M5 Nut:M5
PDX12A-1-3	20 轴挑线驱动杆 B 组件 20#Drive rod B set	PDX12A-1-23	驱动轴 Drive shaft
PDX12A-1-4	弹垫:M4 Spacer:M4	PDX12A-1-24	驱动器组件 Drive set
PDX12A-1-5	20 轴挑线驱动杆 A 组件 20# Take_up_lever rod set A	PDX12A-1-25	油盒 Oil box
PDX12A-1-6	挡圈 Collar	PDX12A-1-26	半圆头十字螺丝:M4X8 Screw:M4X8
PDX12A-1-7	挑线杆驱动轴 Shaft	PDX12A-1-27	标准型弹性垫圈Φ5 Spring waher:Φ5
PDX12A-1-8	内六角凹端紧定螺丝:M4X4 Screw:M4X4	PDX12A-1-28	内六角圆柱头螺丝:M5X10 Screw:M5X10
PDX12A-1-9	内六角圆柱头螺丝 :M4X8 Screw:M4X8		
PDX12A-1-10	铁凸轮四件套Φ20 轴 Cam set Φ20		
PDX12A-1-11	尼龙凸轮Φ20 轴 Cam for shaft Φ20		
PDX12A-1-12	腰型平垫圈:4X8 Spacer:4X8		
PDX12A-1-13	六角螺母:M6 Nut:M6		
PDX12A-1-14	标准型弹性垫圈Φ6 Spring waher:Φ6		
PDX12A-1-15	2 号销 Pin 2		
PDX12A-1-16	轴承: 688ZZ Bearing:688ZZ		
PDX12A-1-17	高速驱动连杆 Drive rod		
PDX12A-1-18	20 轴 1 号销 20# Pin 1		
PDX12A-1-19	小连杆 Rod		
PDX12A-1-20	3 号销 Pin 3		




PDX12A TAPPING DEVICE PDX12A-2

序号 Item No.	名称 Description	序号 Item No.	名称 Description
PDX12A-2-1	气缸:CJPB 10-14 Air cylinder:CJPB 10-14		
PDX12A-2-2	调节阀 Valve		
PDX12A-2-3	M10 螺母 (气缸自带) Nut:M10		
PDX12A-2-4	挡圈 Collar		
PDX12A-2-5	挑线杆夹块 Take_up_lever holder		
PDX12A-2-6	挑线杆组件 Take_up_lever set		
PDX12A-2-7	连接螺母 Nut		
PDX12A-2-8	挑线杆复位弹簧 Take_up_lever return spring		
PDX12A-2-9	挑线杆轴 Take_up_lever shaft		
PDX12A-2-10	内六角圆柱头螺丝 :M4X8 Screw:M4X8		
PDX12A-2-11	内六角凹槽紧定螺丝: M4X4 Screw:M4X4		
PDX12A-2-12	挑线杆导向销 Pin		
PDX12A-2-13	分离轴 Shaft		
PDX12A-2-14	分离隔套 Shaft sleeve		
PDX12A-2-15	离合销 Clutch pin		
PDX12A-2-16	内六角凹槽紧定螺丝:M5X5 Screw:M5X5		




PDX12A TAPPING DEVICE PDX12A-3

序号 Item No.	名称 Description	序号 Item No.	名称 Description
PDX12A-3-1	PDX12 针杆 Needle bar		
PDX12A-3-2	上死点缓冲垫 Cushion		
PDX12A-3-3	导向块安装座 Seating base		
PDX12A-3-4	针杆连接销 Needle bar connecting pin		
PDX12A-3-5	小拨叉连接套 Sleeve		
PDX12A-3-6	内六角凹槽紧定螺丝:M3X3 Screw:M3X3		
PDX12A-3-7	内六角圆柱头螺丝:M4X8 Screw:M4X8		
PDX12A-3-8	内六角圆柱头螺丝:M4X12 Screw:M4X12		
PDX12A-3-9	过线簧 Spring for thread		
PDX12A-3-10	针杆导向块 Needle bar holder		
PDX12A-3-11	平垫:Φ4 Waher:Φ4		
PDX12A-3-12	标准型弹性垫圈:Φ4 Waher:Φ4		
PDX12A-3-13	外六角头螺丝:M4X8 Screw:M4X8		
PDX12A-3-14	PDX12 轴套 Shaft sleeve		
PDX12A-3-15	平垫:Φ3 Waher:Φ3		
PDX12A-3-16	弹垫:Φ3 Spring waher:Φ3		
PDX12A-3-17	内六角圆柱头螺丝:M3X10 Screw:M3X10		
PDX12A-3-18	滚针轴承:16*20*17 Bearing:16*20*17		
PDX12A-3-19	PDX12 压脚提升套 Foot pressure lifting sleeve		
PDX12A-3-20	压脚套 Pressure foot sleeve		




PDX12A TAPPING DEVICE PDX12A-4

序号 Item No.	名称 Description	序号 Item No.	名称 Description
PDX12A-4-1	压脚提升导向轴 Shaft	PDX12A-4-21	弹垫:Φ4 Spring washer:Φ4
PDX12A-4-2	小毛毡圈 Felt spacer	PDX12A-4-22	内六角圆柱头螺丝:M4X12 Screw:M4X12
PDX12A-4-3	外六角螺丝:M4X4 Screw:M4X4	PDX12A-4-23	隔套 A Collar A
PDX12A-4-4	厚平垫:Φ4 Washer:Φ4	PDX12A-4-24	同步带轮组件 Timing pulley part
PDX12A-4-5	小拨叉 Small fork	PDX12A-4-25	轴承:MF115ZZ Bearing:MF115ZZ
PDX12A-4-6	提升架 A 组件 Lifting support A part	PDX12A-4-26	带轮销轴 Pin
PDX12A-4-7	隔套 Collar	PDX12A-4-27	内六角凹槽紧定螺丝:M4X6 Screw:M4X6
PDX12A-4-8	压板 Pressing plate	PDX12A-4-28	同步带:90MXL-5 Belt:90MXL-5
PDX12A-4-9	弹垫:Φ3 Spring washer:Φ3	PDX12A-4-29	轴承: 605ZZ Bearing:605ZZ
PDX12A-4-10	内六角圆柱头螺丝:M3X10 Screw:M3X10	PDX12A-4-30	隔套C Collar C
PDX12A-4-11	提升连接块 Lifting connecting block		
PDX12A-4-12	压脚复位簧 Foot pressure return spring		
PDX12A-4-13	CS 压脚主动轮抱箍 Wheel circle		
PDX12A-4-14	压脚主动轮 Active wheel		
PDX12A-4-15	压脚升降电机17K1D7905ABZG16 Foot pressure lifting motor		
PDX12A-4-16	内六角圆柱头螺丝: M3X12 Screw:M3X12		
PDX12A-4-17	提升电机座 Lifting motor base		
PDX12A-4-18	内六角沉头螺丝:M3X6 Screw:M3X6		
PDX12A-4-19	白锌螺母:M5 Nut:M5		
PDX12A-4-20	平垫:Φ4 Washer:Φ4		




PDX12A TAPPING DEVICE PDX12A-5

序号 Item No.	名称 Description	序号 Item No.	名称 Description
PDX12A-5-1	M 轴电机 (M motor: 70H2P086-6004AZ10-181EZ-150)	PDX12A-5-21	定位块 Blcok
PDX12A-5-2	内六角圆柱头螺丝: M5X18 Screw:M5X18	PDX12A-5-22	内六角圆柱头螺丝:M4X14 Screw:M4X14
PDX12A-5-3	弹垫:Φ5 Spring waher:Φ5	PDX12A-5-23	滑环 Circle
PDX12A-5-4	内六角圆柱头螺丝: M5X10 Screw:M5X10	PDX12A-5-24	同步带 :5M-340-15 Belt :5M-340-15
PDX12A-5-5	电机支架 A Motor support A		
PDX12A-5-6	电机支架 B Motor support B		
PDX12A-5-7	电机支架 C Motor support C		
PDX12A-5-8	轴承: 6000ZZ Bearing:6000ZZ		
PDX12A-5-9	M 轴主动带轮组件 (10mm 孔) M Driven active pulley set		
PDX12A-5-10	10mm 紧圈 10mm ring		
PDX12A-5-11	弹垫:Φ4 Spring waher:Φ4		
PDX12A-5-12	内六角圆柱头螺丝:M4X20 Screw:M4X20		
PDX12A-5-13	平垫:Φ4 Waher:Φ4		
PDX12A-5-14	固定块 Block		
PDX12A-5-15	内六角凹槽紧定螺丝:M4X4 Screw:M4X4		
PDX12A-5-16	小连杆垫圈 Small rod washer		
PDX12A-5-17	轴承:F686ZZ Bearing:F686ZZ		
PDX12A-5-18	M 轴限位滑环 M Circle		
PDX12A-5-19	限位销 Pin		
PDX12A-5-20	大盘带 M 轴被动带轮组件 M Driven positive pulley set		



PDX12A TAPPING DEVICE PDX12A-6

序号 Item No.	名称 Description	序号 Item No.	名称 Description
PDX12A-6-1	大盘带摆杆导向轴 Shaft	PDX12A-6-21	内六角圆柱头螺丝:M4X18 Screw:M4X18
PDX12A-6-2	小毛毡圈 Felt spacer	PDX12A-6-22	摆杆电机连杆 Shift motor rod
PDX12A-6-3	针杆复位簧 Needle bar return spring	PDX12A-6-23	驱动销 Pin
PDX12A-6-4	弹簧制动块 Stop block	PDX12A-6-24	摆杆小连杆 Rod
PDX12A-6-5	齿条缓冲垫 Cushion spacer	PDX12A-6-25	旋转臂组件 Rolling set
PDX12A-6-6	连杆 Rod	PDX12A-6-26	摆杆销套 Sleeve
PDX12A-6-7	弹垫:Φ3 pring waher:Φ3	PDX12A-6-27	摆杆 Rod
PDX12A-6-8	内六角圆柱头螺丝:M3X8 Screw:M3X8	PDX12A-6-28	M4 垫片:4X12X1 M4 waher:4X12X1
PDX12A-6-9	内六角凹槽紧定螺丝:M3X3 Screw:M3X3	PDX12A-6-29	内六角圆柱头螺丝:M4X14 Screw:M4X14
PDX12A-6-10	内六角圆柱头螺丝:M3X12 Screw:M3X12	PDX12A-6-30	连接板压簧 Connection board spring
PDX12A-6-11	大拨叉 Big fork	PDX12A-6-31	连接板转动销 Pin
PDX12A-6-12	摆杆导向套 Collar	PDX12A-6-32	平垫:Φ3 Washer:Φ3
PDX12A-6-13	PDX12 挂钩 Hook	PDX12A-6-33	连接板 Connection board
PDX12A-6-14	大拨叉连接块 Connecting block	PDX12A-6-34	绳子导管 2 Pipe 2
PDX12A-6-15	弹垫:Φ4 Spring waher:Φ4	PDX12A-6-35	导管支架 Pipe support
PDX12A-6-16	内六角圆柱头螺丝:M4X12 Screw:M4X4	PDX12A-6-36	摆杆驱动滚柱 Pillar
PDX12A-6-17	内六角圆柱头螺丝:M3X6 Screw:M3X6	PDX12A-6-37	摆杆驱动销 Pin
PDX12A-6-18	摆杆电机 Motor: 17K1D7905ABZG16		
PDX12A-6-19	摆杆电机座 Swing level motor base		
PDX12A-6-20	平垫Φ4 Washer:Φ4		



PDX12A TAPPING DEVICE PDX12A-7

序号 Item No.	名称 Description	序号 Item No.	名称 Description
PDX12A-7-1	十字槽盘头螺丝:M4X8 Screw:M4X8	PDX12A-7-21	波形弹垫: Φ5 Spring washer:Φ5
PDX12A-7-2	上盖板 Cover plate	PDX12A-7-22	连接销 Connection pin
PDX12A-7-3	跳跃电机连杆 Motor rod	PDX12A-7-23	下面板 Bottom plate
PDX12A-7-4	跳跃电机复位簧 Return spring	PDX12A-7-24	十字槽盘头螺丝:M4X8 Screw:M4X8
PDX12A-7-5	轴承:MR115ZZ Bearing:MR115ZZ		
PDX12A-7-6	连杆轴 Rod shaft		
PDX12A-7-7	六角螺母: M4 Nut: M4		
PDX12A-7-8	内六角圆柱头螺丝:M3X6 Screw:M3X6		
PDX12A-7-9	内六角圆柱头螺丝 :M3X8 Screw:M3X8		
PDX12A-7-10	跳跃电机座 Motor base		
PDX12A-7-11	平垫:Φ4 Washer:Φ4		
PDX12A-7-12	弹垫:Φ4 Spring washer:Φ4		
PDX12A-7-13	内六角圆柱头螺丝: M4X14 Screw:M4X14		
PDX12A-7-14	Motor:42H047-0854-004		
PDX12A-7-15	安装板 Mounting plate		
PDX12A-7-16	内六角圆沉头螺丝:M3X8 Screw:M3X8		
PDX12A-7-17	限位挡块 Stopper block		
PDX12A-7-18	限位块 Stopper		
PDX12A-7-19	手动定位块 Block		
PDX12A-7-20	平垫:Φ5 Washer:Φ5		

PDX12A TAPPING DEVICE PDX12A-8

序号 Item No.	名称 Description	序号 Item No.	名称 Description
PDX12A-8-1	内六角圆柱头螺丝:M4X12 Screw:M4X12	PDX12A-8-21	波形弹垫: Φ5 Spring washer:Φ5
PDX12A-8-2	弹垫:Φ4 Spring washer:Φ4	PDX12A-8-22	平垫:Φ5 Washer:Φ5
PDX12A-8-3	平垫:Φ4 Washer:Φ4	PDX12A-8-23	PDX12 绕线轮架侧板 B Wheel racket B
PDX12A-8-4	塑料螺钉:M4X12 Screw:M4X12	PDX12A-8-24	平垫:Φ5 Washer:Φ5
PDX12A-8-5	绕线轮张紧簧 Tension spring for rope		
PDX12A-8-6	盖形螺母:M5 Nut:M5		
PDX12A-8-7	弹垫: Φ5 Spring washer:Φ5		
PDX12A-8-8	绕线轮架侧板A Wheel racket A		
PDX12A-8-9	大盘带张紧弹簧片 Tension spring for rope		
PDX12A-8-10	绕线轮支撑 Wheel support		
PDX12A-8-11	内六角圆柱头螺丝: M4X10 Screw:M4X10		
PDX12A-8-12	导带簧 Spring		
PDX12A-8-13	内六角半圆头螺丝:M3X6 Screw:M3X6		
PDX12A-8-14	PDX12 绕线轮轴 Shaft		
PDX12A-8-15	绕线轮 110 Wheel(Dia: 110mm)		
PDX12A-8-16	定位弹簧片 Spring sheet		
PDX12A-8-17	压紧弹簧片 Spring sheet		
PDX12A-8-18	弹垫:Φ3 pring washer:Φ3		
PDX12A-8-19	内六角圆柱头螺丝:M3X4 Screw:M3X4		
PDX12A-8-20	连接销 Connection pin		